
FRONT OPEN SERIES

Wall Mount



Step 1.

Unplug the cord of the lightbox before installation.

Step 2.

Remove the acrylic face with the supplied suction cap.

Step 3.

Place the light box body to the installation position, mark the fixing point and cord position.

Step 4.

Depend on the position of the external power supply, feed the cable first before fix the lightbox.

Step 5.

Choose the appropriate screws or bolt base on the material and the condition of the wall.

Step 6.

Fix the lightbox accordingly.

Step 7.

Connect the supplied DC adaptor to the AC power, then plug the lightbox into the DC adaptor.

Step 8.

Mount the artwork on the inside of the acrylic faces with double sides tape or opitonal magnetic strips.

Step 9.

Replace the acrylic faces back on to the lightbox. The magnet should position the face automatically.

Step 10.

Plug the power cord and turn on the power.

